
NO.10 SET BATTEN
NO.7 LIGHT BATTEN
NO.4 LIGHT BATTEN
NO.9 SET BATTEN
WHITE HORIZONT CURTAIN
(MANUAL)
BLACK HORIZONT CURTAIN
(MANUAL)
NO.3 SET BATTEN (MANUAL)
NO.5 UPPER HORIZONT
LIGHT BATTEN
NO.2 SUSPENSION
NO.2 SET BATTEN (MANUAL)
NO.1 SET BATTEN (MANUAL)
NO.8 SET BATTEN
NO.7 LEG CURTAIN
NO.3 SUSPENSION
NO.6 HEAD CURTAIN
NO.5 SET BATTEN
NO.2 SUSPENSION
NO.4 LEG CURTAIN
NO.3 SET BATTEN
NO.2 SET BATTEN
NO.1 SUSPENSION
NO.1 LEG CURTAIN
SET BATTEN (FIXED)
NO.1 ELECTRIC CEILING
NO.2 ELECTRIC CEILING
SIDE GALLERY
SIDE GALLERY
SIDE GALLERY
SIDE GALLERY
DN
UP
DN
UP
DIMMER ROOM
OPERATING ROOM
SET BATTEN
(FIXED)
SET BATTEN
(FIXED)